



uGI1 Micro GPS Interrupter

Configuration and Operation Guide



uGI1 Basic



uGI1S Advanced

Print Date:
March 9, 2018

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 1 of 34	REV: 1.03

RESTRICTED PROPRIETARY INFORMATION

This information disclosed herein is the exclusive property of Mobiltex® Data Ltd. And is not to be disclosed without the written consent of Mobiltex® Data Ltd. No part of this publication may be reproduced or transmitted in any form or by any means including electronic storage, reproduction, execution or transmission without the prior written consent of Mobiltex® Data Ltd. The recipient of this document by its retention and use, agrees to respect the security status of the information contained herein.

This document is intended for limited circulation.

The information contained in this document is subject to change without notice and should not be construed as a commitment by Mobiltex® Data Ltd. unless such commitment is expressly given in a covering document. Mobiltex® and corTalk® are registered trademarks of Mobiltex® Data Ltd.

© Copyright Mobiltex® Data Ltd. (2015-2018). All rights reserved.

CURRENT REVISION APPROVALS (Revision 1.03)

Name	Location	Job Function	Signature	Date
Tony da Costa	Calgary	Engineering Manager		
Jerry Chilibecki	Calgary	Director of Engineering		

REVISION HISTORY

Rev	Start Date	Approval Date	Description	Prepared By
Draft 0.01	Oct 15, 2015		First draft.	Tony da Costa
1.00	Oct 16, 2015		Original release.	Tony da Costa
1.01	April 13, 2016		Added iOS/Android app instructions.	Tony da Costa
1.02	Nov 24, 2016		Added uGI1S information	Tony da Costa
1.03	Mar 6, 2018		Added SRL2 information	Tony da Costa

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 2 of 34	REV: 1.03

Table of Contents

1	Introduction	5
2	General Safety Information	6
3	uGI1 Kits and Parts.....	7
4	Configuration.....	12
4.1	Configuration Equipment Requirements	12
4.2	PC Software Installation	12
4.2.1	Driver Installation	13
4.2.2	Configuration Application Installation	13
4.2.3	Adobe Acrobat Reader XI	14
4.3	uGI1 Configuration and Extraction	15
4.3.1	uGI1 Communications and Status	15
4.3.1.1	Defaults.....	15
4.3.1.2	Read Config From uGI1	15
4.3.1.3	Write Config To uGI1.....	15
4.3.1.4	Link Status	16
4.3.1.5	Factory Options.....	16
4.3.1.6	Firmware.....	16
4.3.1.7	Serial#.....	16
4.3.1.8	Read/Write Config File.....	16
4.3.1.9	Read Faults	16
4.3.1.10	Detailed Status	16
4.3.1.11	Event Recorder	17
4.3.1.12	Reboot uGI1.....	18
4.3.1.13	Set uGI1 Clock	18
4.3.1.14	Test Transmission (uGI1S).....	18
4.3.2	Profile Tabs.....	18
4.3.2.1	Mode.....	19
4.3.2.2	Relay Options	19
4.3.2.3	Cycle Parameters	20
4.3.2.4	Schedule Options	20
4.3.2.5	Satellite Communications (uGI1S Only)	21
4.3.3	General Options	21
4.4	Tablet/Phone Application	21
5	Operation	23
5.1	SRL1 Smart Relay Installation	23
5.2	SRL2 Smart Relay Installation	25
5.2.1	Input Terminals.....	25
5.2.2	Output Terminals	25
5.2.3	uGI1 Control Connector	25
5.2.4	Power Connector	26
5.2.5	LED Indicators.....	27
5.2.6	Mount Points.....	27
5.2.7	Wiring Connections To Source/Load	27
5.3	External Relay Installation.....	28
5.4	uGI1 Mounting	28
5.5	uGI1 Operation	29
5.6	LCD Display.....	31
6	Firmware Updates.....	32
A.	uGI1 Equipment Specifications	34

Figures

Figure 1 uGI1 Basic Micro GPS Synchronized Interrupter	5
Figure 2 uGI1S Advanced Micro GPS Synchronized Interrupter w/Satellite Communications	5
Figure 3 uGI1S Advanced Communications Block Diagram	5
Figure 4 uGI1Installer Dialog.....	12
Figure 7 Driver Installation Screen.....	13
Figure 5 uGI1 Configuration Application Installation Dialog	13
Figure 6 uGI1 Configuration Application Installation Complete	14
Figure 8 uGI1CONFIG Main Screen.....	15
Figure 9 Faults Dialog	16
Figure 10 Detailed Status Dialog.....	17
Figure 11 Extract Event Recorder File Dialog	17
Figure 12 Sample Event Recorder File.....	18
Figure 13 Relay Options.....	19
Figure 14 Cycle Parameters.....	20
Figure 15 Schedule Options.....	20
Figure 16 General Options.....	21
Figure 17 Phone Application Sample Screenshots	22
Figure 18 uGI1 Power Connections (AC voltage from rectifier taps or DC voltage connections).....	23
Figure 19 uGI1 Connector Alignment Arrow.....	23
Figure 20 SRL1 Relay Contacts Installed In Series With Taps (Tap Bar Removed While In Use)	24
Figure 21 SRL1 LED Indicators.....	24
Figure 22 SRL2 Features Labelled	25
Figure 23 uGI1 Connector Alignment Arrow.....	26
Figure 24 SRL2 Power Cable Clips To Rectifier Taps.....	26
Figure 25 SRL2 Connections To Source and Load	27
Figure 26 Connecting a Solid State Relay or a Mercury	28
Figure 27 Mounted On Top of a Rectifier Cabinet (uGI1 LCD Display Facing Down)	28
Figure 28 Examples of Mobiltex padlock installation	29
Figure 29 Master Lock 8417D Installation (Cable Fits Through uGI1 Lock Holes).....	29
Figure 30 LCD display layout	31
Figure 31 uGI1 Firmware Update Application Dialog	32
Figure 32 uGI1 Firmware Update Application Progress	33

1 Introduction

The uGI1 is a reliable low cost interruption controller designed for use with cathodic protection rectifiers. Precise timing accuracy and repeatability is attained with GPS and microprocessor technology. Compact single package construction and a wide operating temperature range make this device ideally suited for corrosion field survey activities.

Two model variants of the uGI1 are available. The uGI1 Basic provides GPS synchronization of the interruption waveform. The uGI1S Advanced unit adds two-way satellite communications to the capabilities of the basic model. The advanced unit communicates with the corTalk® corView website for remote control and monitoring. Events such as interruption start/stop and SRL1 smart relay current faults can be communicated to corView during operation.



Figure 1 uGI1 Basic Micro GPS Synchronized Interrupter



Figure 2 uGI1S Advanced Micro GPS Synchronized Interrupter w/Satellite Communications




Figure 3 uGI1S Advanced Communications Block Diagram

This document details the configuration and operation of the uGI1 product.

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 5 of 34	REV: 1.03

2 General Safety Information

The following safety precautions must be reviewed to avoid injury and prevent damage to this product or any products connected to it. To avoid potential hazards, use this product only as specified. If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

Only qualified personnel should perform service procedures.

While using this product, you may need to access other parts of a larger system. Read the safety sections of the other component's manuals for warnings and cautions related to operating the system.

To Avoid Fire or Personal Injury

Connect and Disconnect Properly. Do not connect or disconnect terminal wiring while the wires are connected to a voltage source.

Observe All Terminal Ratings. To avoid fire or shock hazard, observe all ratings and markings on the product. Consult the product manual for further ratings information before making connections to the product. Do not use an input marked with measurement category I for measurements within measurement categories II, III or IV. Do not connect category II inputs directly to mains—a Class 2 CSA/UL transformer must be used for isolation.

Do Not Operate Without Covers. Do not operate this product with covers or panels removed.

Avoid Exposed Circuitry. Do not touch exposed connections and components when power is present.

Do Not Operate With Suspected Failures. If you suspect there is damage to this product, have it inspected by qualified service personnel.

Symbols and Terms

Terms in this Manual. These terms may appear in this manual:

WARNING. Warning statements identify conditions or practices that could result in injury or loss of life.

CAUTION. Caution statements identify conditions or practices that could result in damage to this product or other property.

Terms on the Product. These terms may appear on the product:

DANGER. Danger indicates an injury hazard immediately accessible as you read the marking.

WARNING. Warning indicates an injury hazard not immediately accessible as you read the marking.

CAUTION. Caution indicates a hazard to property including the product.

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 6 of 34	REV: 1.03

3 uGI1 Kits and Parts

Kit A20A03UGI01 (Basic Version, No Relay):

	A1506031001 uGI1 Base Unit
	H20712UGI01 Black uGI1 Soft Case
	W16400UGI07 uGI1 External Relay Interface Cable

Kit A20A03UGI02 (Basic Version With SRL1 Smart Relay Configuration):

	A1506031001 uGI1 Base Unit
	H20712UGI01 Black uGI1 Soft Case
	A1506031501 SRL1 Smart Relay

Kit A20A0331901 (Advanced Version With Satellite Comms, No Relay):

	A1506031901 uGI1 Advanced Base Unit
	H20712UGI01 Black uGI1 Soft Case
	W16400UGI07 uGI1 External Relay Interface Cable

Kit A20A0331902 (Advanced Version With Satellite Comms and SRL1 Smart Relay Configuration):


	A1506031901 uGI1 Base Unit
	H20712UGI01 Black uGI1 Soft Case
	A1506031501 SRL1 Smart Relay



Programming Kit A20A03UGI03

	W164DIUGI01 uGI1 USB Programming Cable
	U14971USB08 8GB USB Drive w/uGI1 Configuration Software

Additional Optional Accessories:

	W16400UGI02 3 Meter (10') Relay Extension Cable
	W16400UGI03 8 Meter (26') Relay Extension Cable (Do not use with Mercury relays)
	A20A03UGI04 uGI1 to 5/6 pin SPI1 Relay Adapter Cable Includes Adapter Cable P/N W16400UGI05 and Power Injector Cable P/N W16400UGI06.
	W16400UGI07 uGI1 External Relay Interface Cable
	A1506031501 SRL1 AC/DC Smart Relay
	X03912B150A Medium Heatsink to Increase SRL1 Capacity to 50A
	A20A0333801 SRL2 DC Smart Relay Kit (100VDC/100ADC Max) Includes SRL2 Relay P/N A1506033801, Control Cable P/N W16400SRL20, Power Cable P/N W16400SRL21 and 2 Yellow Clips P/N H27400112YL.
	A1506033801 SRL2 DC Smart Relay (100VDC/100ADC Max)
	W16400SRL20 SRL2 Control Cable

	W16400SRL21 SRL2 Power Cable
	H27400112YL Yellow Clip For SRL2 Power Cable (2 Required Per Cable)
	A20103SRL20 Optional High Current Jumper Cable Kit for SRL2 Includes 600mm (24") Red Superflex 6AWG ¼" to 3/8" Lug Cable (A02100SRL04) and 600mm (24") Black Superflex 6AWG ¼" to 3/8" Lug Cable (A02100SRL03)
	H00000LOCK1 30*30.5*13.5mm Brass Cylinder Padlock With 2 Keys
	T01A42TR201 Class II 20VA 12VAC Transformer for 120/230VAC Primary (Custom Lightning Immune Design)
	P10309A121A 12VA 12VAC Wall Plug-in Transformer for 120VAC
	T01A422512C Class II 20VA 12VAC Transformer for 120/240/277/480VAC Primary
	K0513245010 Solid State AC Relay - 24-280 VAC RMS 50 Amps max (0-8A=No Heatsink, 8-50A=Needs HE-54)
	K0513211010 Solid State AC Relay - 24-280 VAC RMS 110 Amps max (0-8A=No Heatsink, 8-60A=HE-54, 60-110A=HE-90)
	K0513285010 Solid State AC Relay - 48-530 VAC RMS 50 Amps max (0-8A=No Heatsink, 8-50A=Needs HE-54)
	K05232R5016 Solid State AC Relay - 3 phase, 48-530 VAC RMS 50 Amps max (0-4A=No Heatsink, 4-30A HE-90 & special holes)
	X0301292B80 Small Heatsink for Solid State Relay - HF92B-80 (Max 15 Amps with any of the above Solid State AC Relays)

	X03912P5400 Medium Heatsink for Solid State Relay - HE-54		
	X030320HE90 Large Heatsink for Solid State Relay - HE-90		
	K07111NC12D Mercury Relay - 240 VAC @ 100 A, 48 VDC @ 100 A, 125 VDC @ 50 A		
	K07111060NC Mercury Relay - 480 VAC @ 60 A, 48 VDC @ 60 A, 125 VDC @ 40 A		

4 Configuration

4.1 Configuration Equipment Requirements

The following items will be needed when configuring an uGI1 with a PC.

- uGI1 Programming Kit (A20A03UGI03) Includes USB cable P/N W164DIUGI01 and Programming Application and Driver Media (USB flash drive) P/N U14971USB08.

To use a PC to communicate with the uGI1, you will require the media (USB flash drive) that shipped with the uGI1. The media contains drivers and the uGI1 configuration application. If you do not have the media, the contents can be downloaded from the Mobiltex web site at the following URL.

<http://www.mobiltex.com/cathodic/ugi1>

- Personal Computer (PC)

The application software and drivers require that the PC be running Windows 7 or higher for an operating system. The PC must have an available USB port.

When configuring the uGI1 through a tablet or phone, the following is needed.

- Android device with Bluetooth Smart (BLE) capability and Android OS version 4.4 (KitKat) or higher.
or
- Apple iPhone or iPad with Bluetooth Smart (BLE) capability and iOS 8.1 or higher.

4.2 PC Software Installation

To install the configuration application and driver software, insert the media (USB flash drive) that came with the configuration interface into a USB port on the PC. Use Windows Explorer to navigate to the media drive or the directory containing the installation software. Double-click on the “uGI1INSTALLER.exe” application. The dialog on Figure 4 will appear.




Figure 4 uGI1Installer Dialog

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 12 of 34	REV: 1.03

4.2.1 Driver Installation

To prevent potential hardware driver issues in Windows, do not attach the uGI1 to the PC USB port before installing the device drivers.

From the uGI Installer screen, click the “Install uGI1 USB Interface Drivers” button. **Note that to install drivers, you must be logged into the PC with an account that has administrative privileges.** The following screen should display. Follow the installation instructions presented by the driver installer application.




Figure 5 Driver Installation Screen

Once the driver installer completes, you may then plug in the uGI1 through the USB cable into an available USB port on the PC.

4.2.2 Configuration Application Installation

Click on the “Install uGI1 Configuration Application” button to start the application installer. A security warning dialog may appear--click the “Run” button to continue.

The following dialog should now appear:




Figure 6 uGI1 Configuration Application Installation Dialog

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 13 of 34	REV: 1.03

Follow the instructions presented in the installation screens, clicking “Next” to move to the next screen each time. Some screens may pause for tens of seconds as the Windows installation procedure is processing. The final screen should show the dialog in Figure 7. Click “Close” to complete the installation.




Figure 7 uGI1 Configuration Application Installation Complete

A shortcut to the configuration application and the uGI1 manual are created in the Windows start menu under the “uGI1 Configuration Application” folder.

4.2.3 Adobe Acrobat Reader XI

Adobe Acrobat Reader XI is provided on the installation media to allow viewing of the PDF version of the uGI1 manual. If Acrobat Reader is already installed on the PC, it is not necessary to re-install it. To install Acrobat Reader, click on the “Install Adobe Acrobat Reader XI” button on the uGI Installer dialog, and follow the instructions provided by the Acrobat Reader installation application.

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 14 of 34	REV: 1.03

4.3 uGI1 Configuration and Extraction

Attach the supplied USB cable between the PC and the uGI1.

Start the configuration software by clicking on “uGI1 Configuration” shortcut in Windows start menu, under the “uGI1 Configuration Application” folder. The following screen will appear.




Figure 8 uGI1CONFIG Main Screen

The current settings can be exported to a human-readable text file by selecting the “Export Settings To Text Editor” menu item in the “File” menu.

4.3.1 uGI1 Communications and Status

4.3.1.1 Defaults

A factory defaults version of the uGI1 configuration can be loaded into the uGI1 by clicking on the “Defaults” button followed by clicking the “Write Config To UGI1” button.

4.3.1.2 Read Config From uGI1

The first step in configuring a device is to read in the current settings from the unit. Click on “Read Config From uGI1”. The “Link Status” field will briefly show “Busy” as the current configuration parameters are read from the uGI1. After the link status returns to “Idle”, you will see the configuration settings currently in the uGI1. If the uGI1 is not responding or not connected, an error dialog will pop up. If it is not connected, simply connect the USB cable to the computer and try again. If the uGI1 LCD display is showing ‘bUSY’, wait until the ‘bUSY’ indication goes away before attempting to read the configuration from the uGI1.

Once communications have been established with the uGI1, the operational parameters can be configured for the requirements of a particular interruption session.

4.3.1.3 Write Config To uGI1

Once all configuration items have been set as desired, click the “Write Config to uGI1” button to write the configuration to the uGI1 and activate it. Writing parameters to the uGI1 will cause the unit to reboot after completion of the write operation.

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 15 of 34	REV: 1.03

4.3.1.4 Link Status

The “Link Status” field will indicate “Disabled”, “Busy” or “Idle”. While “Busy” is shown, the application is actively communicating with the uGI1 hardware. The application will not respond to further actions while “Busy” is displayed.

The uGI1 can be unplugged at any time from the USB port. However if you have changed any parameters, be sure to write them to the uGI1 before unplugging the device.

4.3.1.5 Factory Options

The “Factory Options” box will display any factory configured options.

4.3.1.6 Firmware

The “Firmware” box will show the firmware version of the uGI1 that was last read.

4.3.1.7 Serial#

The “Serial#” box will show the electronic serial number of the uGI1 that was last read.

4.3.1.8 Read/Write Config File

The “Write Config To File” button may be used to store a copy of the current configuration to a file on the PC. The configuration may be retrieved by using the “Read Config From File” button. After loading the configuration from a file, it must still be written to the uGI1 before the changes become effective.

4.3.1.9 Read Faults

The “Read Faults” button is used to read out any faults that might be present within the uGI1. The information present in this box should be sent to Mobiltex for analysis when faults are encountered.




Figure 9 Faults Dialog

4.3.1.10 Detailed Status

The “Detailed Status” button causes a pop-up window to appear. The window includes detailed information about several items used by the uGI1.

The GPS Status information may be used to diagnose GPS satellite signal reception issues that may prevent time lock from occurring. Ideally, more than 3 satellites should be in the fix for a reliable lock.

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 16 of 34	REV: 1.03




Figure 10 Detailed Status Dialog

4.3.1.11 Event Recorder

The “Extract Event Recorder” button allows extraction of the event data from the uGI1 into a CSV file. Data is extracted in UTC (GMT) time. When the “Extract Event Recorder” button is clicked the following save as screen will prompt the user for the storage filename.




Figure 11 Extract Event Recorder File Dialog

The stored file is saved in a comma separated value (CSV) format that can be imported into spreadsheets (i.e. Excel) and other applications that support CSV import. Note that older versions of Excel support a maximum of 65,000 lines so large event files may not be completely displayed when using those Excel versions. Excel versions prior to and including version 2003 will have this limitation.

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 17 of 34	REV: 1.03

The CSV file is arranged as indicated in the following Excel screen capture. The first line contains header information which identifies the contents of each column.

A	B	C	D	E	F	G	H	I	J	K	L	M
Record Index	Record Category	Record Type	Date/Time(UTC)	Excel Time(UTC)	Input(Volts)	Profile Mode	On Time(ms)	Off Time(ms)	On First	No GPS	Relay Type	Interruption Status
1	Power	Power-up(898669,1.01)	10/15/2015 13:36:04	10/15/2015 13:36:04	19.2							
2	Notes	Notes	10/15/2015 13:36:04	10/15/2015 13:36:04								
3	Profile	Start	10/15/2015 13:36:04	10/15/2015 13:36:04		Always Interrupting	2000	1000	No	No	Solid State	Interrupt Waiting
4	GPS	Status	10/15/2015 13:36:04	10/15/2015 13:36:04								
5	GPS	Status	10/15/2015 13:36:06	10/15/2015 13:36:06								
6	Profile	Interrupter Change	10/15/2015 13:36:09	10/15/2015 13:36:09		Always Interrupting	2000	1000	No	No	Solid State	Interrupting
7	Profile	Change	10/15/2015 13:36:11	10/15/2015 13:36:11		Always Interrupting	2000	1000	No	No	Smart Relay SRL1	Interrupting
8	Smart Relay	Info(SRL1,850002,1.020,10-15-2015)	10/15/2015 13:36:11	10/15/2015 13:36:11								
9	Smart Relay	On Validation Failure	10/15/2015 13:36:22	10/15/2015 13:36:22								
10	Profile	Change	10/15/2015 13:36:48	10/15/2015 13:36:48		Always Interrupting	2000	1000	No	No	Solid State	Interrupting
11	Power	Power-up(898669,1.01)	10/15/2015 13:37:19	10/15/2015 13:37:19	19.5							
12	Notes	Notes	10/15/2015 13:37:19	10/15/2015 13:37:19								
13	Profile	Start	10/15/2015 13:37:19	10/15/2015 13:37:19		Always Interrupting	2000	1000	No	No	Solid State	Interrupt Waiting
14	GPS	Status	10/15/2015 13:37:19	10/15/2015 13:37:19								
15	GPS	Status	10/15/2015 13:37:21	10/15/2015 13:37:21								
16	Profile	Interrupter Change	10/15/2015 13:37:25	10/15/2015 13:37:25		Always Interrupting	2000	1000	No	No	Solid State	Interrupting
17	Profile	Change	10/15/2015 13:54:55	10/15/2015 13:54:55		Always Interrupting	2000	1000	No	No	Smart Relay SRL1	Interrupting
18	Smart Relay	Info(SRL1,850002,1.020,10-15-2015)	10/15/2015 13:54:55	10/15/2015 13:54:55								
19	Smart Relay	On Validation Failure	10/15/2015 13:54:55	10/15/2015 13:54:55								
20	Smart Relay	Periodic	10/15/2015 13:55:55	10/15/2015 13:55:55								
21												

N	O	P	Q	R	S	T	U	V	W	X	Y
Latitude	Longitude	Sats Tracked	Sats In Solution	Position Valid	Time Valid	GPS C/NoAv4 (dB)	GPS EHPE(m)	Relay Closed Current (ARMS)	Relay Open Fault	Relay Temperature(C)	Notes
											This is a test of the notes field. Testing 1,2,3.
0	0	0	0 No	No		0	0				
51.08554	-113.99695	2	11 Yes	Yes		37	18.6				
								0 No		26	
											This is a test of the notes field. Testing 1,2,3.
0	0	0	0 No	No		0	0				
51.08551	-113.99689	0	11 Yes	Yes		0	21.8				
								0 No		29	
								0 No		28	

Figure 12 Sample Event Recorder File

After the data has been extracted from the uGI1, the data memory on the device may be cleared by clicking the “Clear Event Recorder” button. Note that clearing memory may take up to 60s to complete.

4.3.1.12 Reboot uGI1

The “Reboot uGI1” is used to restart the uGI1 application.

4.3.1.13 Set uGI1 Clock

The “Set uGI1 Clock” is used to set the clock of the uGI1 from the PC clock. Normally, the uGI1 clock will automatically be set from the GPS receiver as soon as a valid GPS time fix is detected.

If the “No GPS” mode is enabled in the configuration, the uGI1 clock should be set at least once before interruption is attempted to allow for proper time stamps in the internal event recorder. Beyond that, the clock should be updated periodically to resynchronize the clock to actual time. The internal clock of the uGI1 model can be expected to drift as much as +/-10s each month without GPS synchronization. The uGI1 will maintain the real time clock as long as the internal backup battery is not fully depleted.

4.3.1.14 Test Transmission (uGI1S)

Click this button to have the uGI1S send a test message to the corView web site over the satellite transceiver. The uGI1S must be located in an area with sufficient coverage (open view of the sky) to send the message.

4.3.2 Profile Tabs

All items in the “Profile” tabs may be reset back to factory defaults by clicking on the “Defaults” button. Each tab corresponds to a different selectable profile, each with independent configurable options.

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 18 of 34	REV: 1.03

4.3.2.1 Mode

The mode group allows the profile operational mode to be selected. Six types of profiles are available as shown in Table 1.

Mode	Description
Profile Disabled	Profile is disabled and cannot be selected when the profile select button is pressed on the unit.
Rectifier On	Interruption relay is always closed.
Rectifier Off	Interruption relay is always open.
Always Interrupting	The selected cycle parameters are used to drive the interruption relay as soon as the profile is selected. Schedule options are not used. Also allows for No-GPS mode of operation.
Daily Repeat with Start/Stop Schedule	The selected cycle parameters are used to drive the interruption relay as soon as the schedule conditions are met. The schedule start and stop date/times are selected and the uGI1 interrupts from the start date to the stop date, but only between the selected start and stop hours each day.
Continuous With Start/Stop Schedule	The selected cycle parameters are used to drive the interruption relay as soon as the schedule conditions are met. The schedule start and stop date/times are selected and uGI1 interrupts continuously between those two time points.

Table 1 Profile Operation Modes

Depending on the selected profile mode, additional groups will be displayed in the profile tab.

4.3.2.2 Relay Options

The relay used with the uGI1 must be defined so that it is driven correctly. Two pre-defined relay types are available, solid state normally open and Mercury normally closed. In addition, a custom relay type may be defined with individual adjustable parameters for contact type, synchronization to AC line waveform, coil voltage and contact open/close dwell times. When a Mobiltex SRL1 or SRL2 Smart Relay is attached to the uGI1, these parameters settings are ignored as the uGI1 automatically sets the appropriate values.

Relay Options

☐ Solid State (Normally Open)

☐ Mercury (Normally Closed)

☒ Custom

☐ Normally Closed

☒ AC Sync

☐ 6V coil

☒ 12V coil

0 Dwell Close (ms)

0 Dwell Open (ms)

1 Smart Relay Current Threshold (A)


Figure 13 Relay Options

The Smart Relay Current Threshold option allows the unit to log and indicate correct operation of the relay when a Mobiltex Smart Relay (e.g. SRL1 or SRL2) is used with the uGI1. The uGI1 uses this parameter as the comparison value against the measured relay current to determine if correct current is being delivered during the on phase of interruption. If the measured current during the on phase is below this threshold an entry is made in the event logger memory.

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 19 of 34	REV: 1.03

4.3.2.3 Cycle Parameters

The cycle parameters group defines the actual interruption waveform used and its synchronization to UTC time.



The image shows a 'Cycle Parameters' dialog box with the following fields and values:

- On Time (ms): 500
- Off Time (ms): 500
- On First: ☐
- No GPS: ☐
- UTC Offset (ms): 0

Figure 14 Cycle Parameters

“On Time (ms)” sets the duration of the on-phase of the waveform.

“Off Time (ms)” sets the duration of the off-phase of the waveform. The sum of the off time and on time parameters must be less than or equal to 60,000ms. Note that since the uGI1 synchronizes the waveform to the top of the minute, the sum of the on and off times should divide into 60,000ms an integer number of times so as to avoid a short cycle at the top of the minute.


The “On First” option selects the phasing of the waveform relative to the top of the minute. If left unchecked, the unit will transition to the off-phase at the top of the minute. Checked, the unit will transition to the on-phase at the top of the minute.

The “No GPS” option is only available with the “Always Interrupting” mode of operation. When used, the unit will not use GPS information to synchronize the interruption waveform. This can be useful when interrupting a single rectifier in an area where GPS reception is not possible.

“UTC Offset (ms)” is used to slide the interruption waveform in time to align it with other manufacturers’ equipment that may not align exactly with UTC time. Typically, this parameter is left at its default value of 0.

4.3.2.4 Schedule Options

The schedule options group is used to select start/stop times for the interruption profiles.



The image shows a 'Schedule Options' dialog box with the following fields and values:

- Start: 10/16/2015 12:48 PM
- Stop: 10/17/2015 12:48 PM
- Active Days: ☒ Su ☒ Mo ☒ Tu ☒ We ☒ Th ☒ Fr ☒ Sa
- Time Zone Offset From UTC: -6 H 0 M
- Set Time Zone From PC (button)

Figure 15 Schedule Options

“Start” selects the profile start date/time. “Stop” selects the profile stop date/time. When in “Continuous With Start/Stop Schedule” mode, the uGI1 will interrupt 24 hours per day between the start and stop dates when operation spans multiple days. When in “Daily Repeat With Start/Stop Schedule” mode, the uGI1 will interrupt between the start and stop time each day for the selected date range.

“Active Days” allows the schedule to be further controlled to only become active on certain days of the week. The selected days can be used with either schedule type of operation.

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 20 of 34	REV: 1.03

The “Time Zone Offset From UTC” option allows the local time zone offset to be specified. Start and stop date/times are specified in local time. To operate in UTC mode, set this to 0 hours 0 minutes. The “Set Time Zone From PC” button allows the time zone offset to be filled in from the current PC system settings.

4.3.2.5 Satellite Communications (uGI1S Only)

Set the ‘Enable Transceiver’ check box to allow the uGI1S to communicate with the corView website when the selected profile is active. If this check box is not set, the uGI1S will operate identically to a uGI1 Basic unit.

The uGI1S utilizes the Iridium low Earth orbit constellation for communications to corView. The uGI1S must be installed with top dome facing up and with as large a view of the sky as possible (ideally greater than 120 degrees). Do not install the uGI1S inside the rectifier cabinet or any other metal enclosure as the satellite signals will not penetrate.

This option can be toggled for the currently selected profile by holding down the “SEL PROFILE” button on the LCD side of the uGI1 for longer than 10s.

4.3.3 General Options

All items in the “General Options” group may be reset back to factory defaults by clicking on the “Defaults” button. General options are common to all profiles.

Figure 16 General Options

“Event Recorder Enabled” configures the unit to log events in internal memory for later retrieval. This can be useful to later validate that interruption was set correctly, and when using a Smart Relay also validate relay operation through the interruption activity.

“Bluetooth Enabled” allows the unit to be configured and queried using a compatible smart phone or tablet. This option is used in conjunction with the “Bluetooth Pairing Code”; the pairing code must be entered on the smart phone or tablet to allow for successful pairing of the devices. To initiate Bluetooth pairing mode on the uGI1, press and hold the SEL button for 5s until the Bluetooth icon lights up on the LCD screen.

The “Unit Name” parameter is a freeform text box used to identify the unit. This information is included when exporting the configuration information to a text file.

The “Notes” section allows the user to enter freeform text. This text is inserted into the event recorder memory when enabled. A maximum of 256 characters can be entered into this field.

4.4 Tablet/Phone Application

The uGI1 may be configured wirelessly by using an app on an Android device or an Apple iPhone/iPad. The portable device must support Bluetooth Smart (BLE) technology. The required app is downloaded from the Google Play store or the Apple App Store. Search for ‘ugl1’ in the respective app store to locate the app; once located, download and install the app on the device. If the app is not located, then your device may not have the required functionality (i.e. Bluetooth Smart or OS version).

The Bluetooth Smart functionality must be enabled in the uGI1 configuration. The factory default state for this option is enabled. If the option has been disabled through the PC application, then the option must be re-enabled through the PC configuration application before a tablet/phone can be used. Refer to section 4.3.3 for the Bluetooth enable option in the PC configuration application.

Before the tablet/phone app can communicate with the uGI1, it must be paired with the uGI1. Start the app on the tablet/phone. Next, press and hold the ‘SEL’ button on the bottom of the uGI1 for a minimum of 5 seconds, until the Bluetooth icon appears on the top of the uGI1 LCD display. Next, click on the ‘Connect to uGI1’ button in the

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 21 of 34	REV: 1.03

tablet/phone app. If the two have not previously been paired, a pop up on the app will request a pairing code. The default code is ‘123456’.

If the default pairing code has been changed using the PC configuration application, use that value instead. See section 4.3.3 for the Bluetooth pairing code option in the PC configuration application. If the Bluetooth pairing code is forgotten, the PC configuration application must be used to reset it.

At this point, the tablet/phone app should be connected to the uGI1. With subsequent connections between the same tablet/phone and the same uGI1, the pairing procedure will not need to be repeated. Functionality of the tablet/phone app is similar to the PC application. However, the tablet/phone app does not support extracting the event recorder memory.

Updates to the tablet/phone apps are available from the same app store locations where they were originally downloaded.




Figure 17 Phone Application Sample Screenshots

5 Operation

The uGI1 can be powered from an AC or DC voltage source. The acceptable input range is: **8VDC to 52VDC or 6VAC to 36VAC**. Sustained transients above the allowable input range may cause damage to the uGI1; always validate the power source voltage prior to connecting the uGI1. The current draw is dependent on the type of interruption relay and can range from under 1 watt to 6 watts.

The AC line synchronization function will only work when the uGI1 is powered by an AC power source. The uGI1 has internal transient protection and can be directly connected to a suitable location on the rectifier taps. Use a voltmeter to find a tap voltage between 6VAC and 36VAC. **Ensure that the tap voltage is within limits with the protected structure lead disconnected from the rectifier; unloaded transformers (i.e. during the interruption off phase) will output substantially higher voltages than loaded transformers. Avoid powering the uGI1 from the DC side of a rectifier as large transients may occur as the DC current flow is interrupted.**

Connect the two yellow wires to the suitable voltage source. If a suitable tap voltage cannot be utilized, then an AC Class 2 transformer or DC voltage source can be used to power the uGI1. The uGI1 has an integral auto polarity feature so the polarity of the DC source is not important; simply connect the two yellow wires to the suitable DC source.



Figure 18 uGI1 Power Connections (AC voltage from rectifier taps or DC voltage connections)

The SRL1 smart relay or external relay cable connector end mates to the black side connector located on the uGI1. The white arrow on the cable side connector must point to the uGI1 bottom side in the location of the “CABLE ARROW” label. The cable snaps into place when installed and provides a waterproof connection. To remove the cable, simply pull the cable connector away from the uGI1 while grasping the cable over-molded end. The cable can be installed and removed with or without power present on the cable or SRL1.



Figure 19 uGI1 Connector Alignment Arrow

5.1 SRL1 Smart Relay Installation

The SRL1 smart solid state relay can interrupt up to 50 Amps AC or DC when mounted on an optional medium heatsink. If the SRL1 is not mounted on a heatsink it can interrupt up to 25 Amps AC or DC. The acceptable switching voltage is 0-90VDC or 0-70VRMS AC. The relay has an on resistance of 10 milliohms and there are no minimum switching voltage restrictions.

Determine if you wish to interrupt the rectifier DC output (90VDC max.) or a suitable transformer tap location (72VAC max.). Disconnect the primary AC line power from the rectifier and lockout the circuit breaker. If you wish to interrupt the DC rectifier output, then install the two black heavy gauge SRL1 wires in series between the rectifier and protected structure. The black wires are not polarity sensitive.

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 23 of 34	REV: 1.03

If you wish to interrupt using a transformer tap, then remove the rectifier tap bar and install the two black heavy gauge relay wires from the SRL1 in the removed tap bar location. Re-apply rectifier primary power after the connections have been completed and the installation has been inspected.



Figure 20 SRL1 Relay Contacts Installed In Series With Taps (Tap Bar Removed While In Use)

The SRL1 smart relay is capable of measuring the current flowing through the relay contacts. Set the Smart Relay Current Threshold in the parameters for the selected profile with a value that is roughly 50% of the expected rectifier current measurement. This will allow the uGI1 to log current level issues during a survey if the current flow drops below the threshold. For a uGI1 Advanced, this will also send an exception to corView if the current is out of tolerance.



Figure 21 SRL1 LED Indicators

Three LED indicators on the SRL1 convey current status information.

The indicator labeled 'LO' will illuminate orange when the current flowing through the relay during the on phase is below the threshold programmed in the current profile. If an interruption cycle is active, the LED will flash with the cadence of the interruption cycle.

The indicator labeled 'OK=ON, HI=FLASHING' will illuminate solid yellow if the current flow through the relay during the on phase is above the programmed threshold. Additionally, if the current is above capabilities of the relay, the indicator will fast flash yellow (50ms on, 20ms off). If an interruption cycle is active, the LED will flash with the cadence of the interruption cycle.

The final indicator, labeled 'PWR=GRN, FAULT=RED' will illuminate green when power is applied to the relay and no faults are present. If a fault is detected in the relay operation, this indicator will light solid red. Finally, if the temperature of the relay exceeds tolerances (e.g. current too high without adequate external heatsink), the relay will open and this indicator will flash red (150ms on, 50ms off) until the relay temperature drops to acceptable levels.

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 24 of 34	REV: 1.03

5.2 SRL2 Smart Relay Installation

Figure 22 shows the Mobiltex® corTalk® SRL2 normally-open solid-state DC relay. This relay is used for permanent/temporary mount installations where sources up to a maximum of 100V/100A DC are being controlled by the uGI1. Similar to the SRL1, the SRL2 is able to measure the amount of current flowing through the device and convey that information to the uGI1. The device must be installed in a protective enclosure, such as a rectifier cabinet.




Figure 22 SRL2 Features Labelled

5.2.1 Input Terminals

The input terminals on the SRL2 relay attach to the power source being controlled. It is important that both the positive and negative leads from the source be connected to the SRL2 input terminals. **Before enabling power from the source, verify that the positive and negative connections are connected to the appropriate terminals. An incorrect polarity connection from the source will cause permanent damage to the relay.**

The input terminals will accept wires terminated with standard 1/4" ring lugs. To install the ring lug, first remove the 1/4" nut, lock washer, and one flat washer from the input terminal. Next, install the ring lug over the remaining flat washer, then re-install the previously removed flat washer, lock washer and nut. Torque the nut to 5 ft-lbs.

5.2.2 Output Terminals

The output terminals connect to the load in the system. Typically, in a cathodic system, the positive lead will connect to the ground bed and the negative lead will connect to the protected structure (e.g. pipe). Again, both leads from the load must connect directly to the SRL2 relay output terminals. No connection should be made from the load directly to the source, the SRL2 must connect between the source and the load.

5.2.3 uGI1 Control Connector

The connector labelled 'TO uGI' is used to connect the relay to uGI1. Attach one end of cable P/N W16400SRL20, which is included with the relay package, to this connector. The other end of the cable is attached to the uGI1. The cable is used to supply power to uGI1 and also provide the interruption control signal from the uGI1 to the SRL2.

Note the pin one alignment markers on the cable and the mating connectors when connecting the cable ends.

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 25 of 34	REV: 1.03



Figure 23 uGI1 Connector Alignment Arrow

5.2.4 Power Connector

The power connector is attached to a cable that is then connected to a power source. The power source must be between 8-52VDC or 6-36VAC. Operating power input outside the specified range can damage the SRL2 and/or the uGI1.

Connect the circular connector on power cable W16400SRL21, which is included with the relay package, to the mating yellow connector on the SRL2. Ensure that the pin 1 markers on the cable and the mating connector line up before inserting the cable.

The power cable is terminated with banana style plugs on each of the yellow wires. The plugs may be attached directly to banana style receptacles on a power source, or clips may be attached when connecting to bolts. Attach two clips, Mobiltext P/N H27400112YL to allow connection to rectifier tap bolts.



Figure 24 SRL2 Power Cable Clips To Rectifier Taps

Refer to section 5 for limitations on the power source.

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 26 of 34	REV: 1.03

5.2.5 LED Indicators

Three LED indicators on the SRL1 convey current status information.

The indicator labeled ‘AMPS LO’ will illuminate orange when the current flowing through the relay during the on phase is below the threshold programmed in the current profile. If an interruption cycle is active, the LED will flash with the cadence of the interruption cycle.

The indicator labeled ‘OK=ON, HI=FLASHING’ will illuminate solid yellow if the current flow through the relay during the on phase is above the programmed threshold. Additionally, if the current is above capabilities of the relay, the indicator will fast flash yellow (50ms on, 20ms off). If an interruption cycle is active, the LED will flash with the cadence of the interruption cycle.

The final indicator, labeled ‘PWR=GRN, FAULT=RED’ will illuminate green when power is applied to the relay and no faults are present. If a fault is detected in the relay operation, this indicator will light solid red. Finally, if the temperature of the relay exceeds tolerances (e.g. current too high without adequate external heatsink), the relay will open and this indicator will flash red (150ms on, 50ms off) until the relay temperature drops to acceptable levels.

5.2.6 Mount Points

Four slots are provided on the bottom flange of the relay heatsink to allow for mounting to a flat surface. The slots allow four screws to be installed on a spacing of 4.5”(114.3mm) x 4.56”(115.8mm). Up to a #10 screw can be accommodated with the slot dimensions.

5.2.7 Wiring Connections To Source/Load

WARNING: Ensure that any power sources that will be supplying the SRL2 are off while performing wiring.

WARNING: Ensure that all wire used for interconnections meets the voltage, current and temperature requirements for the particular installation site.

WARNING: Ensure that all applicable national and local electrical codes are adhered to when installing this device.

Figure 25 shows a typical connection scenario for the SRL2 relay. Here, a cathodic protection rectifier is attached as a source. Note the polarity of the source connections. A protected structure and ground bed are connected to the output terminals of the relay. Ensure all sources are turned off while installing the relay.

Additional wire jumpers will likely be needed to connect between the relay input terminals and the rectifier output terminals. Mobiltex P/N A20103SRL20 is an optional high current jumper kit that is available for this purpose. The kit includes two 600mm (24”) 6AWG superflex cables with ¼” terminal rings on one end and 3/8” terminal rings on the other end. One jumper cable is red and the second is black.

Installations for other sources such as thermoelectric generators or solar panels will be similar.



Figure 25 SRL2 Connections To Source and Load

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 27 of 34	REV: 1.03

5.3 External Relay Installation

The uGI1 provides a 12VDC @ 0.5 Amp maximum for the interruption relay control signal output. The relay control signal is current limited and protected from external overvoltage and transient conditions. On the external relay cable, the black wire is the negative relay drive output and the red wire is the positive relay drive output. The relay dwell timing and contact type (NC or NO) is configurable in each of the 10 available interruption profiles.

An AC line sync feature is available for installations that switch the primary line signal with an AC solid state relay. AC line sync requires an AC power source (via the yellow power wires) and a random turn-on solid state AC relay. The AC line sync function switches the rectifier transformer on at the zero current crossing of the AC line in order to minimize high inrush currents as a result of constantly switching on an inductive transformer load.

Turn off the primary AC line power from the rectifier and lockout the circuit breaker. Install the user provided installation relay and connect the relay contacts to the appropriate interruption locations. Connect the red and black wires from the external relay cable to the coil or control signal of the relay. Re-apply rectifier primary power after the connections have been completed and the installation has been inspected.




Figure 26 Connecting a Solid State Relay or a Mercury

5.4 uGI1 Mounting

The uGI1 is housed in a waterproof (non-submersible) enclosure intended to be placed outside of the rectifier enclosure. The relay/power cable connection is waterproof when mated to the uGI1. **The device should be positioned outdoors and have a good view of the sky with the corTalk® logo pointing up to the sky. Placement is especially important for the uGI1S Advanced two-way satellite communications.** The bottom base of the uGI1 is magnetic to allow attachment to ferrous mounting surfaces. There are four self-tapping screw (special plastic tapping screws available from Mobiltex) locations on the bottom base that can be used for permanent attachment.



Figure 27 Mounted On Top of a Rectifier Cabinet (uGI1 LCD Display Facing Down)

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 28 of 34	REV: 1.03

An optional padlock for the uGI1 is available from Mobiltex. A Master Lock 130D padlock can also be utilized. Installing the padlock on the uGI1 requires the lock shank to be sequentially positioned in order to pass through the two lock holes on the uGI1.




Figure 28 Examples of Mobiltex padlock installation

A Master Lock Python 8417D cable can also be used to secure the uGI1.



Figure 29 Master Lock 8417D Installation (Cable Fits Through uGI1 Lock Holes)

5.5 uGI1 Operation

The bottom control panel of the uGI1 has two LED's, an LCD display and single pushbutton. Each time the “SEL” button is pressed, the next available profile will be selected. The large single LCD digit displays the selected profile number. The smaller digits and icons will cycle through the specific settings associated with the selected profile.

The “SEL” button is also used for two other functions. If the button is held down for longer than 5s, Bluetooth pairing mode is enabled if the Bluetooth function is enabled. If the button is held down for longer than 10s, the satellite communications capability is toggled for the currently selected profile (uGI1S Advanced only).

The red “INT” LED illuminates whenever the interruption relay has turned off the rectifier. The green “OK” LED illuminates when the uGI1 is ready for interruption or actively interrupting. An OK condition requires: GPS time & position lock, sufficient GPS signal level, proper supply voltage to the uGI1, and AC signal power present (only if AC line sync is selected).

A Windows PC running the uGI1 configuration application can edit and save profiles of the uGI1 using the uGI1 USB cable. The uGI1 will also support profile editing using short range wireless Bluetooth Smart (BLE) communications with suitable (Apple iOS/Android) devices. All factory default profiles assume a 12V, normally open, solid state relay with an open and close dwell of 0mS and the interruption cycle starting in an off phase. The factory default profiles are listed below.

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 29 of 34	REV: 1.03

Profile #	On (mS)	Off (mS)	Cycle Phase	Enabled	Relay	Coil Volts	Contacts	AC Sync	Open Dwell	Close Dwell	Schedule	Daily Repeat	UTC Offset
0	Rectifier always on		-	Yes	Solid State	12V	N/O	Yes	0 mS	0 mS	No	No	0mS
1	700	300	Off First	Yes	Solid State	12V	N/O	Yes	0 mS	0 mS	No	No	0mS
2	800	200	Off First	Yes	Solid State	12V	N/O	Yes	0 mS	0 mS	No	No	0mS
3	1500	500	Off First	Yes	Solid State	12V	N/O	Yes	0 mS	0 mS	No	No	0mS
4	3000	1000	Off First	Yes	Solid State	12V	N/O	Yes	0 mS	0 mS	No	No	0mS
5	4000	1000	Off First	Yes	Solid State	12V	N/O	Yes	0 mS	0 mS	No	No	0mS
6	4500	1500	Off First	Yes	Solid State	12V	N/O	Yes	0 mS	0 mS	No	No	0mS
7	9000	1000	Off First	Yes	Solid State	12V	N/O	Yes	0 mS	0 mS	No	No	0mS
8	12000	3000	Off First	Yes	Solid State	12V	N/O	Yes	0 mS	0 mS	No	No	0mS
9	14000	1000	Off First	Yes	Solid State	12V	N/O	Yes	0 mS	0 mS	No	No	0mS

Table 2 uGI1 Factory Default Profiles

The uGI1 conducts the GPS synchronization at the top of the minute. In order to attain a consistent interruption pattern the user should utilize an interruption cycle that is a whole number divisible by 60 seconds.

A modern, high performance GPS receiver with a high gain antenna is integral to the uGI1. From a cold start condition the GPS receiver will attain a position lock within a minute or two. From a cold start condition it could take a maximum of 11 minutes to attain the exact GPS time including leap second offset. The uGI1 will retain GPS information for approximately 1 month which speeds up GPS reacquisition after the initial cold startup.

For the uGI1S Advanced unit with integral two-way satellite communications, the unit communicates events to the corView website. The corView website can be configured to then forward those events via email to users. Events such as unit power-up/down, interruption start/stop, and current faults detected by the SRL1 relay are autonomously communicated. The current profile interruption schedule and parameters can be changed remotely through the corView website after the uGI1S has been deployed in the field. Ensure that the 'Enable Transceiver' option is enabled for the currently selected profile for this feature to operate. If the option is enabled, the LCD screen will show the "SAT" icon in the top middle of the screen. Validate that the signal strength bars to the right of the "SAT" icon show valid signal; the more bars shown, the better the signal.

5.6 LCD Display

A wide operating temperature range LCD provides the user with profile details and device operation.




Figure 30 LCD display layout

	The large single digit displays the selected profile number (0-9).
	The small digits display interruption timing, start / stop times and load current (when smart relay is used).
ON	Interruption On time.
OFF	Interruption Off time.
START	Interruption schedule start time.
STOP	Interruption schedule stop time.
SCHEDULE	Interruption schedule.
WAIT	Waiting for schedule to start.
FAULT	Displayed when the uGI1 detects an internal fault condition. Detailed fault information may be obtained through PC or mobile configuration applications.
	The interruption cycle phase starts in the ON state.
	The interruption cycle phase starts in the OFF state.
	Selected profile uses AC line sync.
SYNC	AC signal present and AC line sync is operational.
	GPS receiver on and GPS signal strength.
	GPS time lock.
	Displayed when a smart relay is detected.
	Bluetooth connected or pairing mode enabled.
	Satellite transceiver on and satellite signal strength (uGI1S advanced only)
PWR	These LCD features are not used in the present version of uGI1 firmware.

Table 3 uGI1 LCD Icons

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 31 of 34	REV: 1.03

6 Firmware Updates

As required, Mobiltex will periodically release firmware update packages for the uGI1. The firmware is included with the configuration application package. The uGI1 configuration application will warn the user if a firmware update is necessary on an attached uGI1.

To update the uGI1 firmware, exit the uGI1 configuration application and execute the uGI1 Firmware Update application from the Windows start menu. The dialog in Figure 31 will be shown.




Figure 31 uGI1 Firmware Update Application Dialog

To start the firmware update process, first ensure that the uGI1 is connected to a USB port on the computer. Next, click on the 'Program Firmware' button. The application will indicate progress as the firmware is downloaded to the uGI1 (see Figure 32). Do not attempt to interrupt the firmware download process once it has started. Once the message 'uGI1 completed firmware programming' is displayed, exit the firmware update application. The uGI1 will reboot and can then be used immediately with the configuration application.

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 32 of 34	REV: 1.03




Figure 32 uGI1 Firmware Update Application Progress

The latest uGI1 software package may be downloaded from the Mobiltex web site at the following URL:

<http://www.mobiltex.com/cathodic/ugi1>

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 33 of 34	REV: 1.03

A. uGI1 Equipment Specifications

Operating Temperature	-20° to +70° C (-4° to +158° F)
Storage Temperature	-40° to +85° C (-40° to +185° F)
Humidity	0 to 100% RH non-condensing
Maximum Altitude	5000 meters above sea level
Pollution Degree	1
Size	83.5 x 79.5 x 30.6 mm (3.3 x 3.12 x 1.2") uGI1 Basic 83.5 x 79.5 x 45.0 mm (3.3 x 3.12 x 1.77") uGI1S Advanced
Weight	100g (0.22 lbs) uGI1 Basic 172g (0.38 lbs) uGI1S Advanced
Enclosure	UV stable, wide temperature polycarbonate
Operating voltage range	8-52VDC or 6-36VAC
Power	10W watts maximum
Display	Fixed Segment LCD
Timing Accuracy (AC Line Sync Disabled)	+/-0.5 ms
Timing Accuracy (AC Line Sync Enabled)	+8.8/-0.5 ms
Relay Drive Voltage	6 or 12 volts DC
Relay Drive Current	0.5 Amp maximum
Relay Contact Close Dwell	0-255 ms
Relay Contact Open Dwell	0-255 ms
Relay Contact Type	NO or NC
Relay Type	Solid state or mechanical
Off Time	100 – 59,900ms in 1ms steps
On Time	100 – 59,900ms in 1ms steps
Cycle Phase Order	Programmable (off first, or on first)
GMT Time-zone Offset:	+/- 12 hours
UTC Reference Offset Adjustment:	+/-2500ms in 1ms steps
Interruption Profiles	10
Profile Memory	Non-volatile EEPROM
Event Log Memory Size	2,000,000 entries
GPS Receiver	56 or 72-channel u-blox
PC Connection	USB 2.0
Wireless Interface	Bluetooth Smart Ready 4.0
Satellite Transceiver (uGI1S Only)	Iridium SBD9603N module (FCC Q639603N IC 4629A-9603N)

Technical assistance may be obtained from:

Attn: Service Department
Mobiltex Data Ltd.
3640-26th Street NE
Calgary, AB T1Y 4T7
Canada
Tel: (403)291-2770
Main Website: <http://www.cortalk.com>
Service Website: <http://www.mobiltex.com/service>

MOBILTEX® DATA LTD. Calgary, Alberta www.corTalk.com	TITLE: uGI1 Configuration and Operation Guide		
	DOCUMENT NO.: UGI1-MAN-001	SHEET: 34 of 34	REV: 1.03